3x Optical Zoom-Nikkor Lens

4.0 Effective Megapixel CCD

5-Area Multi Autofocus

256 Segment Matrix Metering

12 Versatile Scene Modes

www.nikoncoolpix.com

DIGITAL CAMERA

COOLPIX® 4300

4.0 MegaPixel COOLPIX®

Coolpix® Digital Cameras
Designed for the photographer in you

High Quality Digital To Go

Key features and benefits:

- High-resolution **4.0 *effective* Megapixel CCD**. Record images with a maximum resolution of 2,272 x 1,704 pixels for easy cropping and outstanding print quality.
- **High Quality 3x Optical Zoom-Nikkor lens** for clear sharp images plus 4x digital zoom for 12x total zoom.
- **Exclusive 256-segment Matrix Metering** helps you get great exposures in the most difficult lighting situations.
- **Fully Compatible** with optional Nikon Coolpix converter lenses and accessories. (requires UR-E4 converter adapter)
- **Manual Mode** lets you take control of the camera when you want to get serious.
- Includes **Nikon Coolpix Starter Memory Card.**

Everything you need to get started:

- Wrist Strap AN-E885
- USB Cable UC-E1
- Lens Cap
- Video Cable
- Nikon Coolpix Starter Memory Card
- Rechargeable Li-ion Battery
- Battery Charger MH-53
- NikonView 5 (Coolpix) CD-ROM

Movie Mode
Create up to a 40 second QuickTime™ movie

Shutter Release

Built-in Flash
Auto
Flash Cancel
Red-Eye Reduction
Anytime Flash
Slow Sync

Compatible with optional Nikon Coolpix converter lenses, adapters and accessories.*
(*requires optional UR-E4 adapter)

3x Optical Zoom-Nikkor lens
(38mm – 114mm 35mm equivalent)

One Touch® Upload™

Zoom Control
3x Optical Zoom
4x Digital Zoom
12x Total Zoom

Actual size
(3.9"W x 3"H)
(only 7.9 oz.)

Nikon Coolpix Starter Memory Card Included
Compatible with CompactFlash™ Type I

Quick Review
1.5" LCD Monitor with Quick Review lets you instantly confirm a shot you just took or review any of the other images stored on the CompactFlash™ Card.

Small Picture
Lets you create a smaller copy of an image while in playback mode that is perfect for email, web, or PDA viewing.

Accessible through the Shooting Menu

Five Area AF Multi-Selector

Saturation Mode
Control color saturation

Noise Reduction Mode
Minimize digital artifacts in long exposures

White Balance Bracketing
Ensure proper color balance

12 Scene Modes:

The COOLPIX 4300 features 12 specially programmed modes to automatically handle focus, exposure, white balance and other adjustments that help you take great pictures at the press of a button.

Portrait
Your subject comes out sharply focused with natural skin tones, against a soft, pleasant background.

Night Portrait
Using Slow Sync with Red-Eye Reduction in a scene with an illuminated background, your subject is naturally exposed.

Landscape
Emphasizing depth-of-field, this mode captures distant scenes sharply and clearly, for postcard-like landscape pictures.

Night Landscape
Use this mode to take in the true splendor of a nighttime scene using only ambient light.

Close Up
With precise manual focus area selection and appropriate coloration, this mode makes detailed subjects stand out from the background.

Back Light
The Speedlight fires to brighten subjects that are backlit and would come out dark if no flash was used.

Party/Indoor
In dim light, a slower shutter speed is automatically selected to bring out the background. In extremely low-light situations, the Slow Sync flash fires automatically.

Beach/Snow
When shooting a scene with snow or water in the background, the image is free of grayish tones that are caused by typical underexposure.

Sunset
Exposure is automatically controlled, enabling you to preserve the exquisite, natural beauty of a sunset.

Fireworks
With short shutter-release time lag, slow shutter speed, focus set at infinity, and other specific settings, you can capture fireworks in all their original beauty.



Copy
This mode is convenient when shooting characters printed on white material such as paper or white board. This is a great tool for application in business or at school.

Museum
Disables flash for indoor shooting in venues that do not allow flash.

Coolpix® 4300

Don't be fooled by the small size of this powerful digital camera. With its 4.0 effective Megapixel CCD, the Nikon Coolpix® 4300 brings home high-definition pictures of your every adventure. Featuring a 3x Optical Zoom-Nikkor Lens, a built-in Flash, 5-Area Multi Autofocus, an extra-bright full-color LCD monitor and 12 versatile Scene Modes, the Coolpix® 4300 captures striking images from as close as 1.6 inches. Its sleek ergonomic design provides for a secure grip, maximum comfort, and easy access to a wide range of advanced functions. You'll capture images suitable for large size printing, while the Quick Review, Small Picture and One-Touch Upload™ features make it easy to view and share your pictures. The Coolpix® 4300 even records movies, and is fully compatible with optional Nikon Coolpix converter lenses and accessories. The Nikon Coolpix® 4300. Digital photography was never this much fun.

Digital Camera Specifications:

CCD:	Total number of pixels 4.1 million (4.0 million pixels effective)
Lens:	3x Zoom-Nikkor (4x Digital Zoom) f=8-24mm [35mm camera format equivalent to 38-114mm]
Viewfinder:	Real image optical zoom viewfinder
LCD monitor:	1.5-in. low temp polysilicon TFT LCD
Storage media:	CompactFlash™ card Type I
Built-in Speedlight:	Shooting Range: 1.3 - 12.1 ft. (w), 1.3 - 7.5 ft. (t)
Interface:	USB 1.1 interface Video output (NTSC/PAL selectable)
Power requirements:	Rechargeable Li-ion battery EN-EL1 (included)
Dimensions (WxDxH):	3.7 x 2.7 x 2.0 in. [95 x 69 x 52mm]
Weight (without battery):	approx. 7.9 oz (without battery and memory card)
NikonView 5 System requirements for Macintosh	*OS:* Mac® OS 9.0 - 9.2 (only built-in USB ports supported), Mac® OS X (10.1.2 or later) *Models:* iMac™, iMac™ DV , Power Macintosh® G3 (Blue & White), Power Mac™ G4 or later; iBook™, PowerBook® G3 or later (only built-in USB ports supported) *RAM:* 64MB or more recommended *Hard disk:* 25MB required for installation, with additional amount equivalent to twice the capacity of the camera memory card plus 10MB required when Nikon View 5 is running *Display:* 800 x 600 with thousands of colors (millions of colors recommended) *Others:* CD-ROM drive required for installation
NikonView 5 System requirements for PC	*OS:* Windows® 98SE, Windows® Me, Windows® 2000 Professional, Windows® XP Home Edition, Windows® XP Professional pre-installed model *Models:* Only models with built-in USB ports supported *CPU:* Pentium® 300MHz or faster *RAM:* 64MB (128MB or more recommended) *Hard disk:* 25MB required for installation, with additional amount equivalent to twice the capacity of the camera memory card plus 10MB required when NikonView 5 is running *Display:* 800 x 600 with High Color (True Color recommended) *Others:* CD-ROM drive required for installation
Accessories Included:	Lens cap, Wrist strap, Video cable, Nikon Coolpix Starter Memory Card, USB cable, (1) Rechargeable Li-ion battery EN-EL1, Battery Charger MH-53, NikonView Ver .5 CD-ROM, Open Me First Envelope, Manual
Optional Accessories:	Rechargeable Battery, AC Adapter/Charger, PC card adapter, Wideangle converter, Telephoto converters, Fisheye converter, Slide Copying Adapter, Macro COOL-LIGHT SL-1, Step-down ring adapter UR-E4 (Required to use converter lenses, Slide Copying Adapter and COOL-LIGHT), and Remote Cord
Bundled Software:	NikonView version 5.x, ArcSoft; PhotoImpression™, VideoImpression™, Panorama Maker™
Product number:	25507 018208255078

All products indicated by trademark symbols are trademarked and/or registered by their respective companies. Specifications and equipment are subject to change without any notice or obligation on the part of the manufacturer. 08/02

©2002 NIKON INC.



** requires UR-E4 Converter Adapter*

Additional accessories can be found at **www.nikoncoolpix.com** on the Coolpix 4300 page

LEXAR Media™ ArcSoft™ Digital Imaging • Internet • Entertainment SOFTWARE FOR PEOPLE QuickTime™

Nikon

1300 Walt Whitman Road, Melville, NY 11747

www.nikonusa.com / 1-800-Nikon-UX